

T Series intelligent power controller



Features:

- Three phase power regulator, auto phase detection
- Soft start function to protect SCR and load against surge current
- Integrated display with various LED indicator for status and error display
- Integrated heatsink and fans with temperature detection
- Over temperature alarm, output protection after alarm on(except SCR-51)
- Maximum and minimum output configurable
- Auto/manual control bumpless transfer(except SCR-51)
- Run/stop function
- RS-485 modbus RTU display
- Event input function
- Rated load voltage 380~440Vac 50/60HZ
- Power supply for SCR to work is 220Vac, 380Vac, 12-24VDC optional
- Input, 0-10Vdc, 4-20mA, 0-5Vdc, 1-5Vdc, 2-10Vdc, 0-20mA, 0-10mA
- Rated current options, 40 amps, 60 amps, 75 amps, 100 amps.
- This SCR only compatible with resistive load

Technical Specifications

Ordering Information

T-**1**-**2****3****4****5**-**6****7**

1: Type of SCR power regulators

51	51 series SCR regulator(without alarm and RS-485 function)
6	6 series SCR regulator
7	7 series SCR regulator

2: Load phase

3	3 phase load system
----------	---------------------

3: Load current

4	40 amps 380~440Vac
6	60 amps 380~440Vac
7	75 amps 380~440Vac
1	100 amps 380~440Vac(only SCR-6 with 100 amps option)

3: Power supply for the unit itself

2	220Vac
4	380Vac
D	12-24Vdc

4: Input signal

1	0-10mA
2	0-20mA
8	4-20mA
5	0-5Vdc(potentiometer)
6	0-10Vdc
7	1-5Vdc
3	2-10Vdc

5: Over temperature alarm(This is only available for SCR-6 and SCR-7)

N	without alarm
M	with 1 alarm, relay output

6: Communication(This is only available for SCR-6 and SCR-7)

N	without communication
M	With RS-485 modbus RTU communication

Remark: T-51 series do not have alarm and RS-485 options, only SCR-6 and SCR-7 have alarm and RS-485 option
only SCR-6 series available with 100 amps

eg: SCR-6-3128-NN(SCR-6 3 phase regulator, 100 amps, 4-20mA input)
SCR-7-3728-MM(SCR-7 3 phase regulator, 70 amps, 4-20mA input,
with 1 alarm, with RS-485 communication)

Size and dimensions



Model: T-51-3428 40 amps
overall size:118mm*140mm*118mm
Mounting size:55mm*135mm

Model: T-51-3628 60 amps
overall size:133mm*140mm*118mm
Mounting size:55mm*135mm

Model: T-51-3728 75 amps
overall size:133mm*140mm*118mm
Mounting size:55mm*135mm



Model: T-6-3428 40 amps
overall size:160mm*140mm*145mm
Mounting size:120mm*130mm

Model: T-6-3628 60 amps
overall size:160mm*140mm*145mm
Mounting size:120mm*130mm

Model: T-6-3728 75 amps
overall size:160mm*140mm*145mm
Mounting size:120mm*130mm

Model: T-6-3128 100 amps
overall size:220mm*140mm*145mm
Mounting size:150mm*130mm




Model: T-7-3428 40 amps
overall size:160mm*110mm*148mm
Mounting size:105mm*100mm

Model: T-7-3628 60 amps
overall size:160mm*110mm*148mm
Mounting size:105mm*100mm


Model: T-7-3728 75 amps
overall size:160mm*110mm*148mm
Mounting size:105mm*100mm

Panel description




- INDICATOR**
- OUT: The flashing frequency indicate the output ratio
 - AL1: Over temperature alarm indicator
 - POW: Power feed indicator
 - L1: Phase indicator, when L1 absence, lights on
 - L2: Phase indicator, when L2 absence, lights on
 - L3: Phase indicator, when L3 absence, lights on
 - MAN: Manual control indicator
 - COM: Communication indicator
- SET KEY**
- SET: Parameter setting and configuraion
 - A/M: Manual/auto control switch
 - POW: Power feed indicator
 - <: Left shift key, to shift the display unit
 - v: Decrease key or Stop key



Connection diagram




Fast fuse rated at 1.5*actual load
for example, if the acutal current is 20 amps
then fast fuse should be 30 amps



Input




Performance





Is recommended to work up to 60% of the rated power

Power Up



Power Up



Upper : SCR3
Lower : 1.11



Normal display
Upper display shows heatsink temperature
Lower display shows the input percentage

Configuration flow chart

Menu Level 1

Press SET once to enter Menu Level 1




UAD : To display the communication address
uad=ADD (ADD was preset during the communication setup)
Press SET to password parameter

Passwork "LCK"



SET LCK=101 , Press SET to goes to menu level 1
Press SET

Level 1



AL1
SET a temperature for alarm to be triggered if heatsink temp exceed set value, when AL1 set as "0" , this function disabled

Press SET



EOP
Output value goes down to EOP value if over temperature alarm on
eg : When SCR temp reaches to AL1 alarm, the output goes down to EOP value

Press SET



OPL
Minimum output parameter, Range : 0.0-100.0%
Eg : When there is no signal feed from outside, the SCR still output at OPL value

Press SET



OPH
Minimum output parameter, Range : 0.0-100.0%
Eg : The maximum output can be restrained at OPH value to protect the system

Press SET



BUF
Soft-start parameter , Range:0.0-100.0
The outut change ratio per second
Eg : BUF=10.0 , means that it takes 10 seconds for the SCR output changes from 0.0-100.0% BUF=100.0, soft-start function disabled

Press SET

ADD: communication setting parameter

Range : 0-127

Set Communication address for each SCR



Press SET

BAU

BAU: communication speed

Range : 24:2.4KBPS 48:4.8KBPS 96:9.6KBPS 192:19.2KBPS



Press SET to exit

Level 2

Press SET once to enter

UAD : To display the communication address

uad=ADD (ADD was preset during the communication setup)

Press SET to password parameter



Parameter LCK

Set LCK= 202 , Press SET to goes to auto/manual parameter

Press SET to enter



AUTO(Auto/manual control configuration)

0 : auto/manual function off

1 : auto/manual function on



Press SET

RUN(Run/stop configuration)

0 : Run/stop off

1 : Run/stop on



Press SET

HZ : To choose the power supply frequency



Press SET to exit

Cautions !!!

- *SCR can not be operated without load or load current less than 0.5
- *Please make sure to tighten the screw securely while wiring the SCR, otherwise extra heat will be accumulated on the terminals results a damage on the SCR
- *SCR must be mounted vertically on a solid panel without any objects placed above or beneath the SCR to make sure a smooth air flow
- *If multiple SCR installed at the same control cabinet, the main principle is to make the air flow efficient among each unit
- *The temperature inside of the control cabinet must be lower than 55 celsius, otherwise a cooling fan must be installed
- *If two SCR installed paralleled, the distance between the two units must be more than 5CM
- *It is user's responsibility to make sure your selection on the SCR is compatible with your application
- *For safety consideration, a circuit breaker must be installed between the load and SCR
- *Touch the input and output terminals have the same risk even if there is not current at some certain period while SCR is still working
- *Never ever try to replace the cooling fans when SCR is working
- *Make sure the load voltage compliance with the ratings of SCR
- *Always make sure the wiring goes to the correct negative and positive terminals