

■ Electrical Connection

Size(mm)	Installation
Diagram	
Configuration by USB cable with PC software for input type, range setting	